



Mayline -

Elastic self-sealing liquid for solar heating systems

Elastic self-sealing liquid for solar heating installations with daily leakage of up to 15 litres

Mayline F seals leaks of up to 15 litres per day. The self-sealing liquid is based on the principle of providing a mechanical seal from the outside. Mayline F only functions in the presence of oxygen and is suitable for all materials currently in use (synthetic and metallic). The product provides the seal with a certain elasticity and fully compatible with glycols. The sealing is done in ca. 14 days.

code	package		
5/MYF	5 l canister		
1/MYF	1 l (pack of 12 bottles)		
2/MYF	1 l (pack of 2 bottles)		



Instructions for use

Quantify the system's contents. Clean the system with Mayline Solar before.

Bleed the pumps well after inserting the liquid! Remove or bypass all the filters and screens. Bleed the re-circulation pumps well and leave them in function. Use a loading pump to insert the necessary amount of self-sealing liquid. Bleed the re-circulation pumps again.

 $The \ system \ must \ remain \ in \ function \ for \ at \ least \ 4 \ hours \ at \ maximum \ temperature. \ The \ Mayline \ F \ may \ be \ left \ inside \ the \ system.$

The sealing is done in ca. 14 days.

Important note

Shake the container well before use. Mayline F can be mixed with glycols and antifreezes but NOT with other chemical products. The self-sealing liquid may be left inside the system.

Protect the product from frost.

Mixing proportions

1-2% (1-2 litres of Mayline F for every 100 litres of water).
ATTENTION! THE PRODUCT MUST NOT BE OVER OR UNDER DOSED.











Elastic self-sealing liquid for solar heating systems

WARNING

Contains:: Silicic acid, sodium salt **Hazard statements:**

H319 Causes serious eye irritation. H315 Causes skin irritation. H335 May cause respiratory irritation.

Precautionary statements:

P261 Avoid breathing mist and vapours. P280 Wear protective gloves and face protection. P264 Wash the hands thoroughly after handling. P312 Call a POISON CENTRE or a doctor if you feel unwell. P403+P233 Store in a well-ventilated place. Keep container tightly closed.

Notes			



T +39 0471 052852

F+39 0471 1968339